



SOIL TERMINATION INFORMATION

Uniflo Macerators can be discharged into a soil discharge stack, this is achievable via a pipe boss type soil stack socket or a suitable strap on type boss connector.

It is also possible to connect directly into the sewer at ground level.

The discharge pipe should discharge into the soil gulley at ground level with adequate pipework in the direction of the flowing waste.

Entry made through the wall of the manhole must be sealed to ensure a watertight connection joint. Correct pipe work should be used at all times suitable for under ground. The pipe work should be protected against frost and also against subsidence from the effect of vehicles passing above.

For further information on underground pipe installation please consult an up to date relevant building regulation manual, this should be available from your local council.